

Rotisserie Assembly

- ① Motor
- ② Fork
- ③ Fork
- ④ Handle
- ⑤ Counterbalance
- ⑥ Knurled nut
- ⑦ Rod



Using the Rotisserie Burner (4 & 5 Burner Grills)

If you have a 4 or 5 burner grill, it is capable of performing rear burner rotisserie cooking. The location of the rear burner allows the placement of the basting pan (not included) beneath the food to collect the juices for basting and gravy. To flavor the contents of the basting pan, you can add herbs, onion, garlic or spices. Hams are especially good with the addition of pineapple slices and brown sugar to the basting pan. Light the rear burner as described in the lighting instructions in the grill's owner manual. Once lit, the rotisserie burner will reach cooking temperatures in about 5 minutes. The rotisserie motor is capable of turning approximately a 15 lb. cut of meat or poultry.

WARNING: When using the rotisserie burner DO NOT use the grill burners as this may cause injury of severe burns.

Setting the meat onto the shaft.

Remove the prong that is closest to the motor end of the rotisserie. Skewer the meat with the shaft, making sure that the meat is centered and balanced as evenly as possible. Push the prong into the meat sufficiently to hold it in place. Place the second prong onto the shaft and push it into the meat. Lock the meat into place, by tightening both securing screws. Ensure that any loose parts of the meat are addressed to prevent tangling as the shaft turns.

Using the counterweight

Place the shaft in the motor and switch the motor on. If the shaft doesn't run smooth, or makes a struggling sound, the meat is not properly balanced. Fortunately, you can use the counterweight to balance any unevenness of the food on the rotisserie.

Remove the rotisserie spit from grill. With the food still on the rotisserie, hold one end of the rotisserie in each hand. Allow it to rotate freely. The heaviest point will naturally rotate towards the ground under the influence of gravity. Having found the heaviest side of the rotisserie, you should now position the counterweight so that it points directly upwards, so that it is opposite the heaviest side.

Once the meat is balanced and the shaft is back in the motor, switch the motor on to ensure balancing is complete. If necessary, carry out the procedure again to fine tune the balance point. Not all foods need to be balanced. If the meat is almost perfectly round and is centered properly on the shaft, it is best to not use the counterweight at all.

Finally, you are ready to start cooking. Please be aware that is common for the meat on the rotisserie to change slightly during the first 10-20 minutes of cooking. This can at times cause the meat to separate from the rotisserie forks preventing it from rotating on the spit. It is advisable to check the meat periodically during the initial part of the cooking process and re-attach the rotisserie forks if needed.